




EN - English

## Installation and operating manual

Thermal flow meter

# METPOINT® FLM SF53

FLMSF53LL220 | FLMSF53DL220 | FLMSF53LL400 | FLMSF53DL400



## Content

<b>1. Safety information</b> .....	<b>4</b>
<b>1.1. Pictograms and symbols</b> .....	<b>4</b>
1.1.1. In this documentation.....	4
1.1.2. On the device.....	4
<b>1.2. Signal words according to ISO 3864 and ANSI Z.535</b> .....	<b>4</b>
<b>1.3. Safety instructions</b> .....	<b>5</b>
<b>1.4. Transport and storage</b> .....	<b>6</b>
<b>1.5. Intended use</b> .....	<b>7</b>
<b>1.6. Warranty and liability</b> .....	<b>7</b>
<b>2. Product information</b> .....	<b>8</b>
<b>2.1. Scope of delivery</b> .....	<b>8</b>
<b>2.2. Type plate</b> .....	<b>8</b>
<b>2.3. Product overview and description</b> .....	<b>9</b>
2.3.1. Identification based on product code.....	9
2.3.2. Product description.....	10
2.3.3. Operating principle.....	10
<b>2.4. Control and display elements</b> .....	<b>11</b>
2.4.1. Version with display.....	11
2.4.2. Version with LED.....	11
2.4.3. Direction of flow.....	12
<b>2.5. Dimensions</b> .....	<b>13</b>
<b>2.6. Technical data</b> .....	<b>14</b>
<b>2.7. Measuring ranges</b> .....	<b>15</b>
<b>3. Installation</b> .....	<b>17</b>
<b>3.1. Warning</b> .....	<b>17</b>
3.1.1. Requirements for piping.....	17
3.1.2. Requirements for inlet/outlet sections.....	17
3.1.3. Turning housing.....	18
<b>3.2. Installation</b> .....	<b>19</b>
<b>4. Electrical installation</b> .....	<b>20</b>
<b>4.1. Pin assignment of plug-type connectors</b> .....	<b>20</b>
<b>4.2. Connection options</b> .....	<b>20</b>
4.2.1. Bidirectional RS485 bus system.....	20
4.2.2. Current output 4 ... 20 mA, 3-wire.....	21
4.2.3. MBus.....	21
4.2.4. Galvanically isolated pulse output.....	22
<b>4.3. Connection of METPOINT® BDL</b> .....	<b>23</b>
4.3.1. Bidirectional RS485 bus system.....	23
4.3.2. Current output 4 ... 20 mA, 3-wire.....	24
4.3.3. Galvanically isolated pulse output.....	24
<b>4.4. Connection to METPOINT® BDL compact</b> .....	<b>25</b>
4.4.1. Bidirectional RS485 bus system.....	25
4.4.2. Current output 4 ... 20 mA, 3-wire.....	25
4.4.3. Galvanically isolated pulse output.....	26
<b>4.5. Modbus termination</b> .....	<b>26</b>

<b>5. Start-up</b> .....	<b>27</b>
<b>6. Configuration and operation</b> .....	<b>27</b>
<b>6.1. Display during operation</b> .....	<b>27</b>
<b>6.2. Setup menu</b> .....	<b>28</b>
<b>6.3. Sensor Setup</b> .....	<b>28</b>
6.3.1. Entering pipe inside diameter .....	29
6.3.2. Entering / changing consumption counter value .....	29
6.3.3. Selecting units for consumption, flow, temperature and pressure .....	30
6.3.4. Entering reference conditions.....	31
6.3.5. Setting zero point for low-flow cut-off function .....	32
<b>6.4. Modbus setup</b> .....	<b>33</b>
6.4.1. Modbus settings (2001 ... 2005).....	34
6.4.2. Values register (1001 ...1500).....	34
<b>6.5. Pulse / alarm</b> .....	<b>35</b>
6.5.1. Pulse output .....	35
<b>6.6. User Setup</b> .....	<b>36</b>
<b>6.7. Advanced</b> .....	<b>36</b>
<b>6.8. 4 ... 20 mA</b> .....	<b>37</b>
<b>6.9. Info</b> .....	<b>38</b>
<b>6.10. MBus</b> .....	<b>38</b>
6.10.1. Default communication settings.....	38
6.10.2. Transferred values.....	38
<b>7. Spare parts and accessories</b> .....	<b>39</b>
<b>8. Maintenance and servicing</b> .....	<b>39</b>
<b>9. Cleaning sensor head</b> .....	<b>39</b>
<b>10. Calibration</b> .....	<b>39</b>
<b>11. LED indicator</b> .....	<b>39</b>
<b>12. Declaration of Conformity</b> .....	<b>40</b>

# 1. Safety information

## 1.1. Pictograms and symbols

### 1.1.1. In this documentation



General instructions



Observe installation and operating instructions



General hazard symbol (danger, warning, caution)



General hazard symbol (danger, warning, caution) relating to mains voltage and powered machine parts



The packaging material is recyclable. Dispose of it according to the applicable statutory regulations.



### 1.1.2. On the device



General instructions






General hazard symbol (danger, warning, caution)

## 1.2. Signal words according to ISO 3864 and ANSI Z.535

<b>DANGER</b>	<b>Imminent danger</b> Consequences of non-compliance: serious or even fatal injury
<b>WARNING</b>	<b>Potential danger</b> Consequences of non-compliance: serious or even fatal injury
<b>CAUTION</b>	<b>Imminent danger</b> Consequences of non-compliance: injury and/or damage to property
<b>NOTICE</b>	<b>Additional notes, tips and hints</b> Consequences of non-compliance: inefficient operation, extra maintenance; no risk to persons

### 1.3. Safety instructions


<b>DANGER</b>	<b>Escaping compressed gas</b>
	<p>Risk of serious or even fatal injury from contact with escaping compressed gas or from unsecured plant components.</p> <ul style="list-style-type: none"> <li>• Before carrying out any assembly, installation or maintenance work, depressurise the system. All above work must be carried out by authorised specialist technical personnel<sup>1</sup>.</li> <li>• Use only pressure-resistant installation materials and suitable tools that are in proper working order.</li> <li>• Before pressurising the system, check all unit parts and repair them, if necessary. Open valves slowly to prevent pressure blows during operation.</li> <li>• Make sure that no persons can be injured or objects can be damaged by condensate or escaping compressed gas.</li> <li>• Protect the device parts against vibration and impact.</li> </ul>
<b>DANGER</b>	<b>Mains voltage</b>
	<p>Risk of serious or even fatal injury from electric shock when coming into contact with non-insulated, powered components.</p> <ul style="list-style-type: none"> <li>• For the electrical installation of the device, adhere to all applicable regulations (e.g. VDE 0100 / IEC 60364).</li> <li>• Before carrying out any maintenance work, de-energize the system.</li> <li>• All electrical work must be carried out by authorised specialist technical personnel<sup>1</sup>.</li> <li>• The permissible operating voltage is printed on the type plate and must be strictly adhered to.</li> <li>• All components of the electrical installation on site must be approved and/or bear the CE mark.</li> <li>• A reliably accessible circuit breaker (e.g. power plug or switch) that shuts off all conductors must be installed close to the unit.</li> </ul>
<b>WARNING</b>	<b>Operation of device outside limit range</b>
	<p>If the specified limits are exceeded, there is a risk of device malfunction, potentially resulting in injury and/or damage to property.</p> <ul style="list-style-type: none"> <li>• The device must only be operated for the intended purpose and within the permissible limits specified on the type plate and in the technical data.</li> <li>• From 10 bar, install a high-pressure protection element for safe installation and removal of the device.</li> <li>• Do not operate the device in connection with flammable gases.</li> <li>• Strictly adhere to the prescribed operating times and maintenance intervals.</li> <li>• Observe the prescribed storage and transport conditions.</li> <li>• Prevent condensation on the sensor element. Ensure that the air fed through the device is free of droplets.</li> </ul>


#### <sup>1</sup>Specialist technical personnel

Specialist technical personnel are persons who, due to their professional qualification and knowledge in the field of measuring, control and pneumatic technology, and their knowledge of the applicable statutory regulations, guidelines and standards are in a position to foresee potential dangers in relation to the use of the device and are qualified to perform the tasks described in this manual. Special operating conditions (e.g. aggressive media) require additional knowledge.

**1.4. Transport and storage**

Despite our best efforts regarding packaging, etc., the device might be damaged during transport. Upon receipt, please remove all packaging material and inspect the product for visible damage. If you detect such damage, immediately notify the carrier company and BEKO TECHNOLOGIES GMBH or one of its agents.



<b>CAUTION</b>	<b>Damage caused during transport or storage</b>
	<p>Incorrect transport or storage, or the use of unsuitable lifting equipment might cause damage to the device.</p> <ul style="list-style-type: none"> <li>• The device must only be transported and stored by authorised and suitably trained technical personnel.</li> <li>• If you detect any damage, do not start the device.</li> <li>• Adhere to the permissible storage and transport temperatures (see technical data).</li> <li>• Protect the device against direct sunlight and heat radiation.</li> </ul>



The device must be stored in the original packaging. Seal the packaging and store it in a dry and frost-free room. Ensure that the storage temperature does not exceed the limits specified on the type plate.

Even when packaged, take suitable measures to protect the device against the elements.

While in storage, secure the device so that it cannot topple over or fall, and protect it against vibration.

<b>NOTICE</b>	<b>Recycling of packaging material</b>
 	<ul style="list-style-type: none"> <li>• The packaging material is recyclable. Dispose of the packaging material according to the applicable statutory regulations.</li> </ul>

### 1.5. Intended use

The METPOINT® FLM is a thermal flow meter for the measurement of volume flow, consumption and flow velocity. By default, the device is configured for the measurement of volume flow in m<sup>3</sup>/h, consumption in m<sup>3</sup> and velocity in m/s.

- The METPOINT® FLM is primarily used in compressed air systems. On request, the sensor can be programmed by BEKO TECHNOLOGIES GmbH for the measurement of other gases: nitrogen, argon, helium, carbon dioxide
- The device is not suitable for operation in potentially explosive or aggressive atmospheres.
- Protect the device against direct sunlight and heat radiation.

Operate the METPOINT® FLM only for the intended purpose and within the limit range specified in the technical data. Do not operate the device with any media (fluids, gas/vapour mixtures) other than those listed above. Any other use of the device is deemed improper and poses a risk to persons, property and the environment.

### 1.6. Warranty and liability

All warranty shall be voided, if the METPOINT® FLM is used improperly, for a purpose other than the intended or is operated outside the limits specified in the technical data. In such cases, the manufacturer shall also reject any liability for damages.




Improper operation includes:

- Incorrect installation, commissioning or operation; insufficient maintenance
- Operation with defective components
- Non-compliance with the instructions in this document, in particular the safety instructions
- Modification of the device
- Non-compliance with the prescribed maintenance intervals
- Use of third-party spare parts that have not been approved by the manufacturer

## 2. Product information





### 2.1. Scope of delivery

The table below shows the scope of delivery of the METPOINT® FLM.


Designation	Picture
Calibration certificate	
Connecting cable (5-wire)	
Aligning aid	

### 2.2. Type plate

The type plate is attached to the device housing. It contains all relevant technical data of the METPOINT® FLM. Please have these details to hand when contacting the manufacturer or supplier:

Made in Germany 	<b>METPOINT FLM SF53</b> S/N: 12579143      0 ... 90 m³/h P/N: 4036460      4 ... 20 mA Gas: Air      length: 400 mm Supply: 18 ... 36 V DC      Pmax: 16 bar www.beko-technologies.com	  
--	--	---



Designation	Description
<b>METPOINT® FLM SF53</b>	Type designation
<b>S/N: 12579143</b>	Serial number
<b>P/N: 4036460</b>	Product number
<b>Gas: air</b>	Medium
<b>Supply: 18 ... 36 V DC</b>	Power supply rating
<b>0 ... 90 m³/h</b>	Min./max. measuring range
<b>4 ... 20 mA</b>	Min./max. analog output current
<b>Length: 400 mm</b>	Length of sensor tube
<b>Pmax: 16 bar</b>	Max. permissible operating pressure

<b>NOTICE</b>	<b>Handling of type plate</b>
	Do not remove or cover the type plate, and protect it against damage. For more information regarding the symbols printed on the type plate, see „Pictograms and symbols“ auf Seite 4.



## 2.3. Product overview and description


### 2.3.1. Identification based on product code



### 2.3.2. Product description

The METPOINT® FLM thermal flow meter measures the volume flow, which forms the basis for intelligent energy management. It can be used to identify potential savings, overloads and weak points in a system to improve its efficiency. By measuring the actual flow to the various production units, operators are in a position to make decisions based on facts. The METPOINT® FLM also indicates whether there are any leaks in their system. The METPOINT® FLM thus provides all the information operators need to correctly dimension and configure their system and system components for improved efficiency. The device is equipped with a Modbus RTU(RS485) interface, a 4 ... 20 mA current output, a galvanically isolated pulse output and an optional MBus interface.

### 2.3.3. Operating principle





Two temperature sensors are installed in series in the direction of flow. The first temperature sensor measures the current process temperature, while the second sensor is electrically heated to a temperature that is exactly 40 K above the temperature measured by the first sensor. As the volume flow increases, the sensors would normally cool, but the electric heater of the second sensor prevents such a temperature drop.

The electric energy required to maintain the temperature difference is directly proportional to the volume flow. This energy consumption of the heater is converted into the relevant flow measurements. Taking into account the inside diameter of the pipe, the METPOINT® FLM determines the exact mass flow.


## 2.4. Control and display elements

### 2.4.1. Version with display



NOTICE	Additional information
	For more information regarding the operation of the device, see „Configuration and operation“ auf Seite 27.

### 2.4.2. Version with LED





The METPOINT® FLM features a LED calibration indicator mounted at the top of the housing. After 15 months, the LED begins to flash, indicating that the device needs to be calibrated. The flashing LED does not have any effect on the measuring process, and the device continues to provide accurate measuring signals.

On request, the calibration interval can be adjusted at the factory.



### 2.4.3. Direction of flow

The direction of flow is indicated by the arrows (1) on the housing of the METPOINT® FLM and on the sensor tube.



NOTICE	Additional information
	If necessary, turn the housing (e.g. to change the direction of flow through the device). For more information, see „Turning housing“ auf Seite 18.

2.5. Dimensions



Dimensions		
	Version with display	Version with LED
<b>A</b>	G ½" (ISO 228/1)	
<b>B (mm)</b>	415 (Standard)	418.5 (Standard)
<b>C (mm)</b>	80	
<b>D (mm)</b>	Ø 11.7	
<b>E (mm)</b>	220 (standard), optional: 400	
<b>F (mm)</b>	94	
<b>G (mm)</b>	102	105.5

## 2.6. Technical data

Technical data	
	SF53
Max. operating pressure	16 bar, optional 50 bar
Measuring technique	Calorimetric
Operating temperature	Sensor tube and fittings: -30 ... +140 °C Housing: -30 ... +80 °C
Measured parameters	m <sup>3</sup> /h (factory settings) On the display version, the following units can be chosen: m <sup>3</sup> /min, l/min, l/s, ft/min, cfm, m/s, kg/min, kg/s
Sensor	Pt45, Pt1000
Media	nitrogen, argon, helium, carbon dioxide
Humidity of medium	max. 90 % rH (no droplets)
Power supply	18 ... 36 VDC
Power consumption	max. 5 W
Digital output	RS485 (Modbus RTU)
Analog output	4 ... 20 mA (max. load < 500 Ω)
Pulse output	Floating switch contact Passive: max. 48 VDC 150 mA 1 pulse per m <sup>3</sup> or per litre Unit adjustable at display
Accuracy	± 1.5 % of measured value ± 0.3 % of final value
Display/indicator	Display: TFT 1.8" (resolution: 220 x 167) or service LED
Screw fitting	G½ (ISO 228/1)
Material	Sensor tube and fittings: 1.4301 stainless steel Housing: Powder-coated aluminium Flange: 1.4404 (DIN EN 1092-1)

## 2.7. Measuring ranges

The METPOINT® FLM volume flow sensor can measure flow speeds up to 185.0 m/s and is factory-set to an inside pipe diameter of 53.1 mm. At the analog output of 4 ... 20 mA, this corresponds to:

Rated diameter	Inside $\varnothing$	Volume flow (measuring range limit value in Nm <sup>3</sup> /h)						Max. m/s
		Air *	Air **	Ar**	CO2**	N2**	N2O**	
Inch	mm							
<b>1/4"</b>	6.0	9.42	8.7	14.7	9.3	8.4	9.2	185.0
	10.0	30.08	27.7	47.0	29.8	26.7	29.5	185.0
	15.0	77.68	71.4	121.4	76.9	69.1	76.2	185.0
<b>1/2"</b>	16.1	90.98	83.7	142.2	90.0	80.9	89.2	185.0
<b>3/4"</b>	21.7	177.84	163.5	278.0	176.0	158.1	174.4	185.0
<b>1"</b>	25.0	243.88	224.2	381.2	241.4	216.9	239.1	185.0
	26.0	265.20	243.8	414.6	262.5	235.8	260.0	185.0
	27.3	294.72	271.0	460.7	291.7	262.1	289.0	185.0
	28.5	323.32	297.3	505.4	320.0	287.5	317.0	185.0
	30.0	361.08	332.0	564.5	357.4	321.1	354.1	185.0
<b>1 1/4"</b>	32.8	436.69	401.5	682.7	432.2	388.3	428.2	185.0
	36.0	531.48	488.7	830.8	526.0	472.6	521.1	185.0
	36.3	541.06	497.5	845.8	535.5	481.1	530.5	185.0
<b>1 1/2"</b>	39.3	639.84	588.3	1000.2	633.3	568.9	627.4	185.0
	40.0	663.68	610.2	1037.5	656.9	590.1	650.8	185.0
	41.9	728.41	669.7	1138.7	720.9	647.7	714.2	185.0
	43.1	777.34	714.7	1215.2	769.4	691.2	762.2	185.0
	45.8	882.17	811.1	1379.0	873.1	784.4	865.0	185.0
<b>2"</b>	50.0	1059.23	973.9	1655.8	1048.3	941.9	1038.6	185.0
	51.2	1112.05	1022.5	1738.4	1100.6	988.8	1090.4	185.0
	53.1	1197.59	1101.1	1872.1	1185.3	1064.9	1174.3	185.0
	54.5	1263.13	1161.4	1974.6	1250.2	1123.2	1238.5	185.0
	57.5	1489.43	1369.5	2328.3	1474.1	1324.4	1460.5	185.0
	60.0	1544.12	1419.8	2413.8	1528.3	1373.0	1514.1	185.0
	64.2	1774.33	1631.4	2773.7	1756.1	1577.7	1739.8	185.0

\* According to DIN 1945 / ISO 1217 (20°C, 1000 mbar), with compressed air.

\*\* Adjustment to DIN 1343: 0°C, 1013.25 mbar

Rated diameter	Inside $\varnothing$	Volume flow (measuring range limit value in Nm <sup>3</sup> /h)						Max.
Inch	mm	Air *	Air **	Ar**	CO <sub>2</sub> **	N <sub>2</sub> **	N <sub>2</sub> O**	m/s
<b>2 1/2"</b>	65.0	1821.03	1674.4	2846.7	1802.3	1619.2	1785.6	185.0
	70.3	2137.86	1965.7	3342.0	2115.9	1901.0	2096.3	185.0
	71.1	2186.80	2010.7	3418.5	2164.3	1944.5	2144.2	185.0
	76.1	2511.24	2309.0	3925.7	2485.4	2233.0	2462.4	185.0
<b>3"</b>	80.0	2778.58	2554.8	4343.6	2750.0	2470.7	2724.5	185.0
	82.5	2958.51	2720.2	4624.9	2928.1	2630.7	2900.9	185.0
	84.9	3133.15	2880.8	4897.9	3101.0	2786.0	3072.2	185.0
	90.0	3525.11	3241.2	5510.6	3488.9	3134.5	3456.5	185.0
<b>4"</b>	100.0	4357.22	4006.3	6811.4	4312.5	3874.4	4272.4	185.0
	107.1	5003.91	4600.9	7822.3	4952.5	4449.4	4906.5	185.0
	110.0	5278.56	4853.4	8251.7	5224.3	4693.6	5175.8	185.0
<b>5"</b>	125.0	6824.50	6274.8	10668.3	6754.4	6068.3	6691.7	185.0
	133.7	7807.53	7178.7	12205.1	7727.3	6942.4	7655.6	185.0
<b>6"</b>	150.0	9839.04	9046.6	15380.8	9738.0	8748.8	9647.6	185.0
	159.3	11096.91	10203.2	17347.2	10982.9	9867.2	10881.0	185.0
	182.5	14581.94	13407.5	22795.1	14432.2	12966.1	14298.2	185.0
	190.0	15805.08	14532.1	24707.2	15642.8	14053.7	15497.5	185.0
<b>8"</b>	200.0	17533.48	16121.3	27409.1	17353.4	15590.6	17192.3	185.0
	206.5	18691.68	17186.2	29219.6	18499.7	16620.4	18327.9	185.0
<b>10"</b>	250.0	27428.75	25219.6	42877.8	27147.1	24389.4	26895.0	185.0
	260.4	29793.76	27394.2	46574.9	29487.8	26492.3	29214.0	185.0
<b>12"</b>	300.0	39544.48	36359.5	61817.6	39138.4	35162.5	38775.0	185.0
	309.7	42143.03	38748.8	65879.8	41710.2	37473.1	41323.0	185.0
	339.6	50673.25	46592.0	79214.6	50152.8	45058.1	49687.2	185.0
	388.8	70301.30	64639.2	109898.0	69579.3	62511.2	68933.3	185.0
	500.0	109845.79	100998.7	171715.7	108717.6	97673.7	107708.2	185.0
	600.0	158177.93	145438.2	247270.6	156553.4	140650.1	155099.9	185.0
	700.0	215297.74	197957.5	336562.7	213086.6	191440.4	211108.2	185.0
	800.0	281205.22	258556.8	439592.2	278317.2	250044.6	275733.1	185.0
900.0	355900.35	327235.9	556358.8	352245.2	316462.7	348974.7	185.0	
1000.0	439383.15	403995.0	686862.7	434870.6	390694.7	430833.0	185.0	


\* According to DIN 1945 / ISO 1217 (20°C, 1000 mbar), with compressed air.

\*\* Adjustment to DIN 1343: 0°C, 1013.25 mbar



### 3. Installation

#### 3.1. Warning

<b>DANGER</b>	<b>Escaping compressed gas</b>
	<p>Risk of serious or even fatal injury from contact with escaping compressed gas or from unsecured plant components.</p> <ul style="list-style-type: none"> <li>• Before carrying out any assembly, installation or maintenance work, depressurise the system. Such work must be carried out by authorised specialist technical personnel only (see „Safety instructions“ auf Seite 5).</li> <li>• From 10 bar, install a high-pressure protection element for safe installation and removal of the device.</li> <li>• Tighten the slotted spring pin with a torque of 20-30 Nm (WS 27).</li> <li>• Use only pressure-resistant installation materials and suitable tools that are in proper working order.</li> <li>• Before pressurising the system, check all unit parts and repair them, if necessary. Open valves slowly to prevent pressure blows during operation.</li> </ul>

#### 3.1.1. Requirements for piping








- Correctly dimensioned gaskets.
- Correctly installed and aligned flanges and gaskets.
- Differences in pipe diameters at joints should not exceed 1 mm. For more information, see ISO 14511.
- Clean, properly installed pipes.


#### 3.1.2. Requirements for inlet/outlet sections

The table below shows the required inlet pipe sections with reference to the direction of flow.

**Table of additional inlet pipe sections required in specific cases**


Flow obstruction <i>upstream</i> of measuring section	Minimum length of inlet pipe section (L1)	Minimum length of outlet pipe section (L-L1)
Slight bend (angle < 90°)	12 x D	5 x D
Reduction (pipe diameter becomes smaller towards measuring section)	15 x D	5 x D
Enlargement (pipe diameter becomes larger towards measuring section)	15 x D	5 x D
90° elbow section or T-piece	15 x D	5 x D
2x 90° elbow sections in a plane	20 x D	5 x D
2x 90° elbow sections change of direction in 3 dimensions	35 x D	5 x D
Shut-off valve	45 x D	5 x D




<b>NOTICE</b>	<b>Deviating measurements</b>
	The above values are required minimum values. If the recommended settling sections cannot be implemented, the measuring deviations might be much greater.

### 3.1.3. Turning housing

If required by the flow direction, the housing can be turned by 180° by loosening the 4 setscrews with 1.5mm hexagon sockets. Align the housing as required and tighten the setscrews again by hand.



NOTICE	Risk of damage to device
	<ul style="list-style-type: none"><li>• Ensure that the connecting pipes are correctly mounted and that the gaskets are installed properly.</li><li>• Using the aligning aid, align the sensor in the direction of flow.</li></ul>


**3.2. Installation**

**The sensor is installed by means of a ½, DN 15 ball valve (min. Ø 15 mm).**

Install the straight fitting with the O-ring (G½ thread, WS 32) in the connecting nozzle. Ensure that the assembly is pressure-tight.


Position the sensor head at the centre of the pipe and align it to the flow direction. To do this, the sensor tube is equipped with a depth scale, arrows indicating the direction of flow and an aligning aid. After the sensor is correctly positioned and aligned, tighten the slotted spring pin with a torque of 20-30 Nm (WS 27).

When tightening the straight fitting and the slotted spring pin, take care not to change the alignment of the sensor. Otherwise, you might need to correct the sensor position and alignment.  
The angle of the sensor should not deviate by more than ± 2° from the ideal position. Larger angles might result in inaccurate measurement.






From an operating pressure of >10 bar, install a high-pressure protection element (prod. no. 4025892). This allows for the installation of the sensor while the system is pressurised, and ensures that the sensor is safely secured at the measuring point.






NOTICE	Additional information
	For more information about the installation of the high pressure protection element, refer to the installation and operating manual shipped with the element.

## 4. Electrical installation

### 4.1. Pin assignment of plug-type connectors


Pin assignment of plug-type connector A, M12 x 1, 5-pin, A-coded (according to EN 61076-2-101)		
Pin assignment of connector Transmitter side	Pin assignment of connector Socket side	Pin assignment of connector Screw side
		

Pin assignment of plug-type connector B, M12 x 1, 5-pin, A-coded (according to EN 61076-2-101)		
Pin assignment of connector Transmitter side	Pin assignment of connector Socket side	Pin assignment of connector Screw side
		

### 4.2. Connection options

#### 4.2.1. Bidirectional RS485 bus system


Connection by means of plug-type connector A.



Pin assignment - sensor		Function	Wire colour
PIN-1	+ U <sub>v</sub>	Plus (+) connection, power supply	brown
PIN-2	Bus A (+)	Non-inverted signal (+) from RS485 interface	white
PIN-3	- U <sub>v</sub>	Minus (-) connection, power supply	blue
PIN-4	Bus B (-)	Inverted signal (-) from RS485 interface	black

4.2.2. Current output 4 ... 20 mA, 3-wire


Connection by means of plug-type connector A.



Pin assignment - sensor		Function	Wire colour
PIN-1	+ U <sub>v</sub>	Plus (+) connection, power supply	brown
PIN-2		not assigned	white
PIN-3	- U <sub>v</sub>	Minus (-) connection, power supply	blue
PIN-4		not assigned	black
PIN-5	+ I <sub>OUT</sub>	Current output	grey

4.2.3. MBus

Connection by means of plug-type connector B.




Pin assignment - sensor		Function	Wire colour
PIN-1		not assigned	brown
PIN-2		not assigned	white
PIN-3		not assigned	blue
PIN-4	MBus	MBus	black
PIN-5	MBus	MBus	grey

### 4.2.4. Galvanically isolated pulse output

Connection by means of plug-type connector B.

Connection diagram for METPOINT® SF53 and METPOINT® BDL




Pin assignment - sensor		Function	Wire colour
PIN-1		not assigned	brown
PIN-2		not assigned	white
PIN-3		not assigned	blue
PIN-4	Pulse	Galvanically isolated pulse	black
PIN-5	Pulse	Galvanically isolated pulse	grey

4.3. Connection of METPOINT® BDL

4.3.1. Bidirectional RS485 bus system

Connection by means of plug-type connector A.

Connection diagram for METPOINT® SF53 and METPOINT® BDL




Pin assignment - sensor		Function	Wire colour	Pin assignment - BDL	
PIN-1	+ U <sub>v</sub>	Plus (+) connection, power supply	brown	PIN-7	+ U <sub>v</sub>
PIN-2	Bus A (+)	Non-inverted signal (+) from RS485 interface	white	PIN-1	(+) A / RS485
PIN-4	Bus B (-)	Inverted signal (-) from RS485 interface	black	PIN-2	(-) B / RS485
PIN-3	- U <sub>v</sub>	Minus (-) connection, power supply	blue	PIN-8	- U <sub>v</sub>

### 4.3.2. Current output 4 ... 20 mA, 3-wire

Connection by means of plug-type connector A.

Connection diagram for METPOINT® SF53 and METPOINT® BDL




Pin assignment - sensor		Function	Wire colour	Pin assignment - BDL	
PIN-1	+ U <sub>v</sub>	Plus (+) connection, power supply	brown	PIN-7	+ U <sub>v</sub>
PIN-5	+ I <sub>OUT</sub>	Current output	grey	PIN-4	Analog IN (+)
PIN-3	- U <sub>v</sub>	Minus (-) connection, power supply	blue	PIN-8	- U <sub>v</sub>
PIN-2		not assigned	white		
PIN-4		not assigned	black		

### 4.3.3. Galvanically isolated pulse output

Connection by means of plug-type connector B.

Connection diagram for METPOINT® SF53 and METPOINT® BDL



Pin assignment - sensor		Function	Wire colour	Pin assignment - BDL	
PIN-1	+ U <sub>v</sub>	Plus (+) connection, power supply	brown		
PIN-4	Pulse	Pulse	black	PIN-4	Analog IN (+)
PIN-5	Pulse	Pulse	grey	PIN-7	+ U <sub>v</sub>
PIN-3	- U <sub>v</sub>	Minus (-) connection, power supply	blue		
PIN-2		not assigned	white		




4.4. Connection to METPOINT® BDL compact

4.4.1. Bidirectional RS485 bus system

Connection by means of plug-type connector A.

Connection diagram for METPOINT® SF53 and METPOINT® BDL compact (digital board)




Pin assignment - sensor		Function	Wire colour	Pin assignment - BDL compact	
PIN-1	+ U <sub>V</sub>	Plus (+) connection, power supply	brown	PIN-1	+ U <sub>V</sub>
PIN-3	- U <sub>V</sub>	Minus (-) connection, power supply	blue	PIN-2	- U <sub>V</sub>
PIN-2	+ A	Non-inverted signal (+) from RS485 interface	white	PIN-7	(+) RS485 (A)
PIN-4	- B	Inverted signal (-) from RS485 interface	black	PIN-8	(-) RS485 (B)
PIN-5		not assigned	grey		

4.4.2. Current output 4 ... 20 mA, 3-wire

Connection by means of plug-type connector A.


Connection diagram for METPOINT® SF53 and METPOINT® BDL compact (analog board)



Pin assignment - sensor		Function	Wire colour	Pin assignment - BDL compact	
PIN-1	+ U <sub>V</sub>	Plus (+) connection, power supply	brown	PIN-1	+ U <sub>V</sub>
PIN-3	- U <sub>V</sub>	Minus (-) connection, power supply	blue	PIN-2	- U <sub>V</sub>
PIN-5	+ I <sub>OUT</sub>	Current output	grey	PIN-5	(+) I
PIN-2		not assigned	white		
PIN-4		not assigned	black		

### 4.4.3. Galvanically isolated pulse output


Connection by means of plug-type connector B.



Pin assignment - sensor		Function	Wire colour	Pin assignment - BDL compact	
PIN-1	+ U <sub>v</sub>	Plus (+) connection, power supply	brown		
PIN-4	Pulse	Pulse	black	PIN-1	+ U <sub>v</sub>
PIN-5	Pulse	Pulse	grey	PIN-8	(+) V - PT
PIN-3	- U <sub>v</sub>	Minus (-) connection, power supply	blue		
PIN-2		not assigned	white		

### 4.5. Modbus termination

If the METPOINT® FLM is the last device in the Modbus system, it must be terminated. The sensor is equipped with a built-in terminator. To terminate the device, loosen the 2 top setscrews at the housing, lift off the lid and set the DIP switch (1) to ON. When closing the sensor housing, ensure that the housing gasket is correctly installed.



### 5. Start-up

To start the METPOINT® FLM, power it and perform the sensor setup as described in „Sensor Setup“ auf Seite 28. Slowly pressurise the pipes.

### 6. Configuration and operation

When the METPOINT® FLM is powered, it is automatically initialised. After this step is completed, the main menu is displayed.



The device menus are operated through two capacitive buttons:



>>UP<<



>>ENTER<<

#### 6.1. Display during operation

Compressed Air

395.38 m<sup>3</sup>/h

78562 m<sup>3</sup>

Gasart / Statusmeldung → Air

HW: 1.02 SW: 1.00 MBID: 127 CAL. 1/4

↑ HW-Version    ↑ SW-Version    ↑ Modbus ID    ↑ Seiten Nr.

#### CAL indicates that calibration is due:

After 15 months, message **CAL** is displayed, indicating that the device needs to be calibrated. This message does not have any effect on the measuring process, and the device continues to provide accurate measuring signals. On request, the calibration interval can be adjusted at the factory.

Press the >>UP<< button to call up pages 2 - 5.

<p>Compressed Air</p> <p>83.25 m/s</p> <p>24.1 °C</p> <p>Air</p> <p>HW: 1.02 SW: 1.00 MBID: 127 CAL. 2/4</p>	<p>Average Min Max</p> <p>Flow: m<sup>3</sup>/h    AV    Min    Max</p> <p>395.38            0</p> <p>207.45            870.87</p> <hr/> <p>Total Counter: m<sup>3</sup></p> <p>78562</p> <p>82.7</p> <hr/> <p>AV-Time: 1440 minutes            3/4</p>	<p>Average Min Max</p> <p>Velocity: m/s    AV    Min    Max</p> <p>83.25            0</p> <p>55.92            152.87</p> <hr/> <p>Temperature: °C</p> <p>24.1            21.3</p> <p>23.7            24.6</p> <hr/> <p>AV-Time: 1440 minutes            4/4</p>
--	---	---

### 6.2. Setup menu

Press the >>ENTER<< button to call up the setup menu.  
The setup menu is password-protected.




Default password (factory settings): 0000 (4 x zero).

If required, change the password by selecting **Setup**→**User Setup**→**Password** .

Press the >>UP<< button to select and to change a value.




Press the >>ENTER<< button to confirm the selection or change.



### 6.3. Sensor Setup


**Setup** → **Sensor Setup**



To make a change, select the respective menu option using the >>UP<< button and confirm by pressing the >>ENTER<< button.


### 6.3.1. Entering pipe inside diameter

Setup → Sensor Setup → Diameter



To change the unit, press the >>UP<< button to select the "Unit" field and confirm by pressing the >>ENTER<< button.

Press the >>UP<< button to select the desired unit and confirm by pressing the >>ENTER<< button 2x.




Press the >>UP<< button to select the value to be changed and confirm by pressing the >>ENTER<< button.

Press the >>UP<< button to enter the new value and confirm by pressing the >>ENTER<< button.


### 6.3.2. Entering / changing consumption counter value

Setup → Sensor Setup → Total Counter




To change the unit, press the >>UP<< button to select the "Unit" field and confirm by pressing the >>ENTER<< button.

Press the >>UP<< button to select the desired unit and confirm by pressing the >>ENTER<< button 2x.




Press the >>UP<< button to select the value to be changed and confirm by pressing the >>ENTER<< button.

Press the >>UP<< button to enter the new value and confirm by pressing the >>ENTER<< button.

<b>NOTICE</b>	<b>Consumption counter value</b>
	When the consumption counter reaches 1,000,000,000 m³, it is automatically reset to 0.

### 6.3.3. Selecting units for consumption, flow, temperature and pressure


Setup → Sensor Setup → Units



To change the unit, press the >>UP<< button to select the "Unit" field and confirm by pressing the >>ENTER<< button.


If there are more possible units that fit on the screen, press the "<<" button to call up the next screen.

Press the >>UP<< button to select the desired unit and confirm by pressing the >>ENTER<< button 2x.




### 6.3.4. Entering reference conditions

Setup → Sensor Setup → Ext. Setup



Enter the reference parameter values.


Setup → Sensor Setup → Ext. Setup → Ref. Pres



To change the reference pressure, press the >>UP<< button to select the "Unit" field and confirm by pressing the >>ENTER<< button.


Press the >>UP<< button to select the desired unit and confirm by pressing the >>ENTER<< button 2x.

Setup → Sensor Setup → Ext. Setup → Ref. Temp



Enter the reference temperature.


Setup → Sensor Setup → Ext. Setup → Filtertime



Under "Filtertime", you can enter an attenuation, provided that a "Filtergrade" is entered.  
Possible values: 0 -10000 in [ms].


### 6.3.5. Setting zero point for low-flow cut-off function

Setup → Sensor Setup → ZP Adjust



Enter the zero point and the low-flow cut-off point.


Setup → Sensor Setup → ZP Adjust → ZeroPnt



If the installed sensor shows a flow rate of > 0 m³/h even if there is no flow, you can enter a zero point for the characteristic.

To delete the cut-off point, press the "CLR" button.  
To return to the previous screen, press the "Back" button.


Setup → Sensor Setup → ZP Adjust → CutOff



The low-flow cut-off function is used to set consumption rates below the entered low-flow cut-off point to 0 m³/h so that they do not cause the consumption counter value to increase.

To delete the cut-off point, press the "CLR" button.  
To return to the previous screen, press the "Back" button.

Setup → Sensor Setup → ZP Adjust → Reset



To reset the entered zero point or the low-flow cut-off point, press the "Reset" button.

To return to the previous screen, press the "Back" button.



## 6.4. Modbus setup

The METPOINT® FLM thermal flow meter is equipped with a RS 485 interface (Modbus RTU). Before starting the sensor, configure the communication parameters

- Modbus ID, baud rate, parity and stop bit

to enable communication with the Modbus master.

### Setup → ModBus Setup

*** ModBus Setup ***			
ID	1	Baudrate	19200
Stop	1	Parity	even
Term.	on	RespDelay	0 ms
Set to Default		Back	

ID	
	2
Back	

Save the settings by pressing the "Save" button.  
To apply the default (factory) settings, press the "Set to Default" button.

*** ModBus Setup ***			
ID	2	Baudrate	19200
Stop	1	Parity	even
Term.	on	RespDelay	0 ms
Set to Default		Save	Cancel

### Default (factory) settings:

Modbus ID: 1  
Baud rate: 19200  
Stop bit: 1  
Parity: even

### Caution:

If the sensor is the last device in the Modbus system, it must be terminated. For details, see chapter „4.5. Modbus termination“ auf Seite 26.

## 6.4.1. Modbus settings (2001 ... 2005)

Modbus register	Register address	Byte	Data type	Description	Default	Read/write	Unit/comment
2001	2000	2	UInt16	Modbus ID	1	R/W	Modbus ID 1...247
2002	2001	2	UInt16	Baud rate	4	R/W	0 = 1200 1 = 2400 2 = 4800 3 = 9600 4 = 19200 5 = 38400
2003	2002	2	UInt16	Parity	1	R/W	0 = none 1 = even 2 = odd
2004	2003	2	UInt16	Number of stop bits		R/W	0 = 1 stop bits 1 = 2 stop bits
2005	2004	2	UInt16	Word order	0xABCD	R/W	0xABCD = big endian 0xCDAB = middle endian


## 6.4.2. Values register (1001 ...1500)

Modbus register	Register address	Byte	Data type	Description	Default	Read/write
1101	1100	4	Float	Flow in m <sup>3</sup> /h		R
1109	1108	4	Float	Flow in Nm <sup>3</sup> /h		R
1117	1116	4	Float	Flow in m <sup>3</sup> /min		R
1125	1124	4	Float	Flow in Nm <sup>3</sup> /min		R
1133	1132	4	Float	Flow in ltr/h		R
1141	1140	4	Float	Flow in Nltr/h		R
1149	1148	4	Float	Flow in ltr/min		R
1157	1156	4	Float	Flow in Nltr/min		R
1165	1164	4	Float	Flow in ltr/s		R
1173	1172	4	Float	Flow in Nltr/s		R
1181	1180	4	Float	Flow in cfm		R
1189	1188	4	Float	Flow in Ncfm		R
1197	1196	4	Float	Flow in kg/h		R
1205	1204	4	Float	Flow in kg/min		R
1213	1212	4	Float	Flow in kg/s		R
1221	1220	4	Float	Flow in kW		R
1269	1268	4	UInt32	Consumption m <sup>3</sup> before decimal point	x	R
1275	1274	4	UInt32	Consumption Nm <sup>3</sup> before decimal point	x	R
1281	1280	4	UInt32	Consumption ltr before decimal point	x	R
1287	1286	4	UInt32	Consumption Nltr before decimal point	x	R
1293	1292	4	UInt32	Consumption cf before decimal point	x	R
1299	1298	4	UInt32	Consumption Ncf before decimal point	x	R
1305	1304	4	UInt32	Consumption kg before decimal point	x	R
1311	1310	4	UInt32	Consumption kWh before decimal point	x	R
1347	1346	4	Float	Velocity m/s		
1355	1354	4	Float	Velocity Nm/s		
1363	1362	4	Float	Velocity Ft/min		
1371	1370	4	Float	Velocity NFt/min		
1419	1418	4	Float	GasTemp °C		
1427	1426	4	Float	GasTemp °F		

### 6.5. Pulse / alarm

#### Setup → Pulse/Alarm

The galvanically isolated pulse output can be used as a pulse or as an alarm output.




The following units can be selected for the alarm output:

- kg/min, cfm, l/s, m<sup>3</sup>/h, m/s, °F, °C, kg/s

Press "Value" to enter the alarm value. Press "Hyst." to enter the desired hysteresis.

**Hi-Lim:** upper limit


**Lo-Lim:** lower limit



The following units can be selected for pulse output:

- kg, cd, l, m<sup>3</sup>

Select "Value" to enter the pulse factor (0.1, 1, 10, 100). Select "Polarity" to enter the switching state (plus = 0 → 1, minus = 1 → 0).



#### 6.5.1. Pulse output

The maximum permissible number of pulses per second is 50. Pulse output is delayed by 1 second.


Pulse factor	[m <sup>3</sup> /h]	[m <sup>3</sup> /min]	[l/min]
0.1 ltr / pulse	18	0.3	300
1 ltr / pulse	180	3	3000
0.1m <sup>3</sup> / pulse	18000	300	300000
1 m <sup>3</sup> / pulse	180000	3000	3000000

Table 1: Maximum flow volumes for pulse output


NOTICE	Important information
	Pulse factors that are unsuitable to represent the measuring range limit value are not permissible. Such entries are discarded and an error message is displayed.

## 6.6. User Setup

Setup → User Setup




On the user setup screen, you can change the password, rotate the display and adjust its brightness.



To change the password, you must enter the new password twice.

## 6.7. Advanced

Setup → Advanced



Press the "Factory Reset" button to reset the METPOINT® FLM to its default (factory) settings.


### 6.8. 4 ... 20 mA

Setup → 4 - 20 mA




On this screen, you can adjust the settings for the 4 ... 20 mA analog output.

Setup → 4 - 20 mA → Channel 1




The following measurements can be configured:

- Flow
- Velocity
- Temperature
- unused = deactivate channel





The screenshot to the left shows the available units for flow. Press the "<<" button to call up the next screen.



The scaling of the 4 ... 20 mA analog output can be set to automatic ("AutoRange = on") or manual ("AutoRange = off").


With "AutoRange = on", the sensor automatically calculates the valid measuring range and associated reference conditions, based on the set pipe diameter.

Select "Scale 4mA" and "Scale 20mA" to manually configure the scaling of the output (precondition: "AutoRange = off").



Enter the scale for 4 mA and 20 mA respectively.

Setup → 4 - 20 mA → Error Current



On this screen, you can enter the error signal to be sent by the analog output in the event of a fault.

- 2 mA = sensor fault / system error
- 22 mA = sensor fault / system error
- None = output according to Namur (3.8 mA ... 20.5 mA)
  - < 4mA to 3.8 mA = value below measuring range
  - > 20 mA to 20.5 mA = value above measuring range


Confirm your entry by pressing the >>ENTER<< button.

6.9. Info

Setup → Info



This screen shows device information.



Press "Details" to view the calibration conditions.

6.10. MBus

6.10.1. Default communication settings

Primary address\*: 1  
 ID: Serial number of sensor  
 Baud rate\*: 2400  
 Medium\*: Gas


6.10.2. Transferred values

Value 1 with [Unit]\*: Flow [m³/h]  
 Value 2 with [Unit]\*: Consumption [m³]  
 Value 3 with [Unit]\*: Velocity [m/s]  
 Value 4 with [Unit]\*: Gas temperature [°C]

\* these values can be factory-set or changed on request.

## 7. Spare parts and accessories

The accessories available for the METPOINT® FLM are listed in the table below.

Designation	Picture
Power supply with plug-type connector A → 4032115	

## 8. Maintenance and servicing

Regularly check the sensor head for dirt and clean it, if necessary. Dirt, dust or oil deposits on the sensor element cause incorrect measurements.

We recommend checking the sensor element at least once a year. If the compressed air is heavily contaminated, choose a shorter inspection interval.

## 9. Cleaning sensor head

To clean the sensor head, immerse it in warm water with a little detergent. Do not clean the sensor with a cloth, sponge, brush or other implement, as any mechanical impact can destroy the sensor. In the event of persistent deposits, return the sensor to the manufacturer for inspection and cleaning.

## 10. Calibration

If the device is not custom-configured, we recommend having it calibrated every 12 months. For calibration, send the METPOINT® FLM to BEKO TECHNOLOGIES GmbH.

## 11. LED indicator

The METPOINT® FLM features a LED calibration indicator mounted at the top of the housing. After 15 months, the LED begins to flash, indicating that the device needs to be calibrated. The flashing LED does not have any effect on the measuring process, and the device continues to provide accurate measuring signals.

On request, the calibration interval can be adjusted at the factory.

12. Declaration of Conformity

**BEKO TECHNOLOGIES GMBH**  
 Im Taubental 7  
 41468 Neuss, GERMANY  
 Tel: +49 2131 988-0  
 www.beko-technologies.com



**EU-Konformitätserklärung**

Wir erklären hiermit, dass die nachfolgend bezeichneten Produkte den Anforderungen der einschlägigen Richtlinien und technischen Normen entsprechen. Diese Erklärung bezieht sich nur auf die Produkte in dem Zustand, in dem sie von uns in Verkehr gebracht wurden. Nicht vom Hersteller angebrachte Teile und/oder nachträglich vorgenommene Eingriffe bleiben unberücksichtigt.

Produktbezeichnung:	<b>METPOINT® FLM</b>
Typ:	<b>SF53 und SF13</b>
Spannungsversorgung:	18 ... 36 VDC
IP-Schutzart	IP65
Max. Betriebsdruck:	16 bar(g)
Min. / Max. Betriebstemperatur:	-30°C / +80°C
Datenblatt:	DB_FLM-0916-FP-A
Produktbeschreibung und Funktion:	Thermischer Massen-Durchflussmesser für Druckluft

**Druckgeräte-Richtlinie 2014/68/EU**

Die Produkte fallen in keine Druckgerätekategorie und sind gemäß Artikel 4 Absatz 3 in Übereinstimmung mit der in den Mitgliedstaaten geltenden guten Ingenieurspraxis ausgelegt und werden dieser entsprechend hergestellt.

**EMV-Richtlinie 2014/30/EU**

Angewandte harmonisierte Normen: EN 61326-1:2013, EN 61326-2-3:2013

**ROHS II-Richtlinie 2011/65/EU**

Die Vorschriften der Richtlinie 2011/65/EU zur Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten werden erfüllt.

Die Produkte sind mit dem abgebildeten Zeichen gekennzeichnet:



Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller.

Neuss, 27.03.2017

Unterzeichnet für und im Namen von:

**BEKO TECHNOLOGIES GMBH**

i.V. Christian Riedel  
 Leiter Qualitätsmanagement International



**BEKO TECHNOLOGIES GMBH**  
 Im Taubental 7  
 41468 Neuss, GERMANY  
 Phone: +49 2131 988-0  
 www.beko-technologies.com



## EU Declaration of Conformity

We hereby declare that the products named below comply with the stipulations of the relevant directives and technical standards. This declaration only refers to products in the condition in which they have been placed into circulation. Parts which have not been installed by the manufacturer and/or modifications which have been implemented subsequently remain unconsidered.

Product designation:	<b>METPOINT® FLM</b>
Types:	<b>SF53 and SF13</b>
Power supply:	18 ... 36 VDC
IP protection rating	IP65
Max. operating pressure:	16 bar(g)
Min./max. operating temperature:	-30°C / +80°C
Data sheet:	DB_FLM-0916-FP-A
Product description and function:	Thermal flow meter for compressed air

### Pressure Equipment Directive 2014/68/EU

The products are not classified in any pressure equipment category. In accordance to article 4, section 3, they have been designed and manufactured according to sound engineering practice as applicable in the EU member states.

### EMC Directive 2014/30/EU

Applied harmonized standards: EN 61326-1:2013, EN 61326-2-3:2013

### RoHS II Directive 2011/65/EU

The products meet the requirements laid down in European Directive 2011/65/EU concerning the restriction of the use of certain hazardous substances in electrical and electronic devices.

The products bear the CE Mark:



This Declaration of Conformity has been issued by the manufacturer.

Neuss, 25/10/2016

Signed on behalf of:  
**BEKO TECHNOLOGIES GMBH**

ppa Christian Riedel  
 Head of International Quality Management





**Headquarters****Deutschland / Germany**

BEKO TECHNOLOGIES GMBH  
Im Taubental 7  
D - 41468 Neuss  
Phone +49 2131 988 0  
beko@beko-technologies.de

**United Kingdom**

BEKO TECHNOLOGIES LTD.  
Unit 11-12 Moons Park  
Burnt Meadow Road  
North Moons Moat  
Redditch, Worcs, B98 9PA  
Phone +44 1527 575 778  
info@beko-technologies.co.uk

**France**

BEKO TECHNOLOGIES S.à.r.l.  
Zone Industrielle  
1 Rue des Frères Rémy  
F - 57200 Sarreguemines  
Phone +33 387 283 800  
info@beko-technologies.fr

**Benelux**

BEKO TECHNOLOGIES B.V.  
Veenen 12  
NL - 4703 RB Roosendaal  
Phone +31 165 320 300  
benelux@beko-technologies.com

中华人民共和国 / **China**

BEKO TECHNOLOGIES (Shanghai)  
Co. Ltd.  
Rm. 606 Tomson Commercial Building  
710 Dongfang Rd.  
Pudong Shanghai China  
P.C. 200122  
Phone +86 21 508 158 85  
info.cn@beko-technologies.cn

**Česká Republika / Czech Republic**

BEKO TECHNOLOGIES s.r.o.  
Na Pankraci 58  
CZ - 140 00 Praha 4  
Phone +420 24 14 14 717  
info.cz@beko-technologies.cz

**España / Spain**

BEKO Tecnológica España S.L.  
Torruella i Urpina 37-42, nave 6  
E - 08758 Cervelló  
Phone +34 93 632 76 68  
info.es@beko-technologies.es

## 中華人民共和國香港特別行政區 /

**Hong Kong SAR of China**

BEKO TECHNOLOGIES LIMITED  
Unit 1010 Miramar Tower  
132 Nathan Rd.  
Tsim Sha Tsui Kowloon Hong Kong  
Phone +852 5578 6681 (Hong Kong)  
Phone +86 147 1537 0081 (China)  
tim.chan@beko-technologies.com

**India**

BEKO COMPRESSED AIR  
TECHNOLOGIES Pvt. Ltd.  
Plot No.43/1 CIEEP Gandhi Nagar  
Balanagar Hyderabad  
IN - 500 037  
Phone +91 40 23080275  
madhusudan.masur@bekoindia.com

**Italia / Italy**

BEKO TECHNOLOGIES S.r.l.  
Via Peano 86/88  
I - 10040 Leini (TO)  
Phone +39 011 4500 576  
info.it@beko-technologies.com

日本 / **Japan**

BEKO TECHNOLOGIES K.K.  
KEIHIN THINK Building 8 Floor  
1-1 Minamiwatarida-machi  
Kawasaki-ku, Kawasaki-shi  
JP - 210-0855  
Phone +81 44 328 76 01  
info@beko-technologies.jp

**Polska / Poland**

BEKO TECHNOLOGIES Sp. z o.o.  
Ul. Pańska 73  
PL - 00-834 Warszawa  
Phone +48 22 314 75 40  
info.pl@beko-technologies.pl

**South East Asia**

BEKO TECHNOLOGIES S.E.Asia  
(Thailand) Ltd.  
75/323 Soi Romklao, Romklao Road  
Sansab Minburi  
Bangkok 10510  
Phone +66 2-918-2477  
info.th@beko-technologies.com

臺灣 / **Taiwan**

BEKO TECHNOLOGIES Co.,Ltd  
16F.-5 No.79 Sec.1  
Xintai 5th Rd. Xizhi Dist.  
New Taipei City 221  
Taiwan (R.O.C.)  
Phone +886 2 8698 3998  
info.tw@beko-technologies.tw

**USA**

BEKO TECHNOLOGIES CORP.  
900 Great SW Parkway  
US - Atlanta, GA 30336  
Phone +1 404 924-6900  
beko@bekousa.com